

Attention: This flyer is an updated version of the LED Feedback. Please use this instead of feedback listed in the instructions

### OVERALL LED FEEDBACK

| LED Light        | Radio Programming Section | Vehicle Programming Section |
|------------------|---------------------------|-----------------------------|
| Solid Green      | Pass                      | Pass                        |
| Slow Red Flash   | Fail                      | Pass                        |
| Slow Green Flash | Pass                      | Fail                        |
| Solid Red        | Fail                      | Fail                        |

### RADIO LED FEEDBACK

| RADIO                   |      | LED PATTERN                                                                                                                                                                                                                                                                                                                                     | KEYNOTES (REFERENCE BELOW) |
|-------------------------|------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------------------------|
| Pioneer/Jensen          | G    |                                                                                                                                                                                                                                                                |                            |
| JVC                     | R    |                                                                                                                                                                                                                                                                |                            |
| KENWOOD                 | GG   |                                                                                                                                                                               |                            |
| SONY/DUAL               | GR   |                                                                                                                                                                               |                            |
| Reserved for future use | RG   |                                                                                                                                                                               |                            |
| ALPINE                  | RR   |                                                                                                                                                                               |                            |
| ALPINE (type 2)         | GGG  |                                                                                              |                            |
| AXXERA                  | GGR  |                                                                                              |                            |
| AXXERA (type 2)         | GRG  |                                                                                           |                            |
| MAGNADYNE               | GRR  |                                                                                        |                            |
| BOSS                    | RGG  |                                                                                        |                            |
| Reserved for future use | RGR  |                                                                                        |                            |
| CLARION (type 1)        | RRG  |                                                                                        |                            |
| CLARION (type 2)        | RRR  |                                                                                        |                            |
| Reserved for future use | GGGG |     |                            |
| Reserved for future use | GGGR |     |                            |
| Reserved for future use | GGRG |     |                            |
| Reserved for future use | GRRR |     |                            |
| Reserved for future use | GRGG |     |                            |
| Reserved for future use | GRGR |     |                            |
| Resistive Radio #1      | GRRG |     |                            |
| Resistive Radio #2      | GRRR |     |                            |
| Resistive Radio #3      | RGGG |     |                            |
| Resistive Radio #4      | RGGR |     |                            |
| Resistive Radio #5      | RGRG |     |                            |
| Resistive Radio #6      | RGRR |     |                            |

- 1) If the LED pattern shows **JVC**, change the radio type to Kenwood. Refer to the Changing Radio Type document.
- 2) If the LED pattern shows **Alpine**, but an **Alpine** radio isn't installed, make sure the 3.5mm jack is plugged into the radio.
- 3) If no SWC, change the radio type to the opposite radio type. Refer to the **Changing Radio Type** document
- 4) **AX-SWC-PARROT** required (sold separately). The software in the radio must be rev. 2.1.4 or higher.